

DIRECTORATE GENERAL BORDER ROADS
GENERAL MAINTENANCE INSTRUCTION NO 191

ON

FARM TRACTOR HMT 5911: MANUFACTURED BY M/S HINDUSTAN MACHINE TOOLS LTD

1. INTRODUCTION

1. Regular servicing and preventive maintenance are essential for optimal usage of equipment to achieve maximum life for planning and timely repair to arrest defects from developing into major one, whereby minimizing the down time and production losses.

2. These instructions are issued as guidelines for scheduled and preventive maintenances and lubrication schedule of Farm Tractor HMT 5911 manufactured by M/S Hindustan Machine Tools Ltd.

ACTION BY.

3. (a) User Units – To carry out scheduled maintenance, Inspection, servicing and preventive maintenance task as laid down by Mobile Maintenance Team.

(b) Field Wksp (GREF) – (i) To monitor the record of maintenance and lubrication as carried out by Mobile Maintenance Team of the equipment during its inspection and repairs when carried out as per maintenance and lubrication schedules given in this instructions.

(ii) To advise user units in respect of any lapses noticed.

DETAILS

4. The details of preventive maintenance are as under:-

- | | | | |
|-----|--------------------------------------|---|----------|
| (a) | Preventive and scheduled maintenance | - | Appx 'A' |
| (b) | Lubrication Chart | - | Appx 'B' |
| (c) | Specifications | - | Appx 'C' |

Dated : 11 Jun 90

Sd xxxxx

(AJS KHALSA)
SE (E&M) SG
Dir Tech
For Dir General Border Roads

Preventive/scheduled maintenance instructions

1. The maintenance of tractor when done and correctly carried out, ensure, the trouble free tractor performance.
2. The following instructions are to be observed carefully:-

GENERAL PRECAUTION

- (a) Daily Task (to be carried out after each 8-10 hrs of operation of tractor).
 - (i) Clean both the tractor and implements.
 - (ii) Replenish fuel and inspect for tightness of the fuel system.
 - (iii) Check water level and inspect for tightness joints of the cooling system.
 - (iv) Check oil level and inspect for tightness joints of lubricating system.
 - (v) Check oil level in the air cleaner and clean the pre- filter removing dust from it.
 - (vi) Check function both of the foot and of hand brake. Check brake liquid level in the jar and hydraulic brake system for tightness.
 - (vii) Inspect the condition of the electrical installation, Check lights trafficator etc. Check the regulator run of running engine, correct lubrication and charging.
 - (viii) Check air pressure in the front and rear tyres, screw on caps and tighten them well.
 - (ix) Check if screw, bolts and nuts of the steering system linkage and leverage and discs both of the front and rear wheels.
 - (x) Check if water pump drive V-belt as well as that of the dynamo are tightened well and correctly. (for sag see Para 2 (a) (v)).
 - (xi) Before starting to drive the tractor with trailer or trailer in toe, check their state as well as the state and condition of coupling and locking elements.
 - (xii) When starting to employ the hydraulic power lift, unscrew the magnetic oil cleaner from its housing. Rinse and blow off the screen and clean magnet. It is recommended to inspect and clean the magnetic oil filter during the starting period of the hydraulic power lift service. Check each 30-50 engine hours the oil level in the injection pump.
- (b) After every 500 litres fuel consumption or after each 100 engine hours. All operation mentioned in Para 2 (a) (i) to (xii) above to be carried out at first.
 - (i) Check oil level in the crankcase oil sump and clean the centrifugal oil cleaner drum rotor.
 - (ii) Inspect oil level in portals.
 - (iii) Inspect oil level in the gearbox.
 - (iv) Unscrew the butterfly nut from the air cleaner, remove the cover and check the condition of the sedimentation in bowl. Untie three bottom quick couplings and remove the complete pre- cleaner upwards (evacuate the dust) and complete air cleaner body downwards. Wash air cleaner jacket, cartridges blade distributor with rebounding plate in petrol or gas oil and dry them before assembly. Suction slots protecting strainer must also be clean. Bolt parts with screw and nut together and put them on to the cleaner bowl filled up before with pure 1.5 liters engine oil upto the relative margin and fix the body to the air cleaner cover. Lubricate the contact surface if the cover and the sealing rubber ring with grease, situated on the cartridge neck.
 - (v) Lubricate the water pump by turning the greasing nipple through one turn and check fan belt sag which is to be maximum of 15 mm.
 - (vi) Oil the clutch-disengaging sleeve.
 - (vii) Lubricate front axle bracket, wheel extensions, shaft to the clutch disengagement, pedals right hand strut, stirrup of the draft control, strut tension nuts and collar with the steering wheel small control lever by means of greasing nipple press.
 - (viii) Inspect the electrolyte level in the storage battery, which should reach 15 mm above, the upper border of plates. Clean corroded cable terminals.
 - (ix) Lubricate the Bowden cable at braked tractor by means of the hand brake with few drops of oil SAE 30.

(c) After every 1000 litres fuel consumption or after each 200 engine hours. All operation mentioned in para 2 (a) (i) to (xii) and 2 (b) (i) to (ix) above to be carried out at first.

- (i) Change oil in the crankcase oil sump, injection pump body and the governor.
- (ii) Clean duly the centrifugal oil cleaner.
- (iii) Replace the cartridge of the coarse fuel filter.
- (iv) Check clearance between the clutch disengagement levers and the sleeve.
- (v) Inspect and necessary clean and set up the injector. Inspect the oil level and replenish if necessary the steering box.

(d) After every 3000 litres of fuel consumption or after each 600 engine hours. All operation mentioned in Para 2 (a) (i) to (xii), (b) (i) to (ix) and (c) (i) to (v) above to be carried out at first.

- (i) Replace the fine fuel filter cartridge.
- (ii) Check valve clearance in a field wksp on the cold engine – both intake and exhaust valve of 0.25+0.05 mm.
- (iii) Check the front wheel toe-in and the divergence as well as the play of the front wheel heads taper roller bearings, replenish the grease in the front wheel heads.
- (iv) Check and adjust the hand brake if necessary.
- (v) Flush the cooling system under the pressure of pure water in order to remove sediments.

(e) After every 6000 litres of fuel consumption or after each 1200 engine hours. All operation mentioned in Para 2 (a) (i) to (xii), (b) (i) to (ix), (c) (i) to (v) and (d) (i) to (v) above to be carried out at first.

- (i) Change oil in the steering box
- (ii) Change oil in the portals.
- (iii) Change the suction strainer of the oil pump.
- (iv) Have checked tightness of the injection pump elements in a Fd wksp.

(e) After every 12000 litres of fuel consumption or after each 1200 engine hours. All operation mentioned in Para 2 (a) (i) to (xii), (b) (i) to (ix), (c) (i) to (v) , (d) (i) to (v) and, (e) (i) to (v) above to be carried out at first.

- (i) Check or have repaired the steering wheel play according to the steering wheel dead point position.
- (ii) Check the charging unit and the starter motor by Fd Wksp.
- (iii) Clean and rinse the radiator with the sodium solution.
- (iv) Turn the front wheel tyre casings with respect to one side wear of them.
- (v) Have ground in engine valves by the Fd Wksp
- (vi) Clean oil in the injection pump.

LUBRICATION CHART FOR HMT 5911 TRACTOR

Lubrication	Maintenance	Capacity	Recommended Lubricants		
			Indian Oil	Hindustan Petroleum	Bharat Petroleum
(1)	(2)	(3)	(4)	(5)	(6)

LUBRICATION CHART FOR HMT 5911 TRACTOR DURING RUNNING IN

Engine	Flush after	10 Lts	Servo Flush 10	Flushing oil	Flushing oil
	50 hrs				
	Change after 50 hrs	12 Lts	Servo super 30 (winter only)	Hylube HDx 30 (winter only)	Actuma T.oil 30 (winter only)
			Servo super 30 (summer only)	Hylube HDx 40 (summer only)	Actuma T.oil 40 (summer only)
FIP	Change after 30 hrs	0.2 Lts	-do-	-do-	-do-
Gear box	Change after 200 hrs	25 Lts	Servo gear 90 HP	HP gear oil EP 90	Spirol 90 EP
Portals	Change	3.8 Lts	-do-	-do-	-do-

	after 200 hrs				
DAILY LUBRICATION AFTER EACH 8-10 OPERATING HOURS					
Engine	Inspection	12 ltrs	Servo super 30 or Super 40	Hylube HDx50 or HDx40	Actuma T.oil 30 or T.oil 40
Air cleaner	Normal dust	No change	Same as engine oil	Same as engine oil	Same as engine oil
	For heavy duty change after 15-20 hrs	1.5 Lts	Same as engine oil	Same as engine oil	Same as engine oil
LUBRICATION AFTER EACH 70 OPERATING HOURS					
Air cleaner	Change	1.5 Lts	Same as engine oil	Same as engine oil	Same as engine oil
Injection	Inspection	0.2 Lts	-do-	do	-do-
Gear box	Inspection	*25 Lts			
Portal both	Inspection	3.8 Lts	-do-	-do-	-do-
Water pump	To be turned by one thread	-	Servo grease MP	Multipurpose grease II	Univex A
Clutch disengaging	To be filled up	0.06 Lts	Same as engine oil	Same as engine oil	Same as engine oil
Front axle pin	Grease thoroughly	0.1 Kg	Servo grease MP	Multipurpose grease II	Univex A
King pins	-do-	0.06 Kg	-do-	do	-do-
Joints of three points linkage	-do-	0.05 kg	-do-	do	-do-
LUBRICATION AFTER 175 OPERATING HOURS					
Engine	Change	12 Lts	Servo super 30 or super 40	Hylube HDx30 or HDx40	Actuma T.oil 30 or T.oil 40

SPECIFICATION OF FARM TRACTOR HMT 5911 FITTED WITH TROLLEY 5 TON CAPACITIES: MANUFACTURED BY M/S HMT LTD

ENGINE

Model	Z 5901
Type	Diesel with direct fuel Injection, 4 stroke, in-line engine water cooled.
No of cylinder	4
Bore of cylinder	100 mm
Stroke	110 mm
Cylinder volume	3465 cm ³
Compression ratio	17:1
Type of cylinder liners	Wet separate for each cylinder
Valve arrangement	Overhead valve system
Fuel consumption	195±5 DIN/2200
Normal engine speed	2200 RPM
Power output HP/RPM	58-5% DIN/
Output class	55-60 HP
Injection timing	24.5°-1-5° before TDC
Air cleaner	Two stage with oil filling (Oil bath)
Cooling	Water cooled with thermostatic control
Lubrication	Splash and positive drive gear pump, with centrifugal full flow oil filter

Capacity of cooling	13 Litres
Capacity of fuel tank	70 litres

FILL UP DATA

Engine oil sump	12 litres
Fuel Injection pump	0.2 litres
Gear box when working with hydraulic lift system:	
On flat ground	25 litres
In hilly grounds	32 litres
Portals	3.8 litres (2x1.9 litres)
Steering box	1.9 litres
Air cleaner	1.5 litres

GEAR BOX

Number of gears	10+2
Speeds of the tractor with T6.9/14.28 tyres at rated engine rpm	

ROAD SPEEDS

1 st gear	7.56 Km/hr
2 nd	11.17 Km/hr
3 rd	15.80 Km/hr
4 th	19.65 Km/hr
5 th	32.90 Km/hr
Reverse gear	13.20 Km/hr

FIELD SPEEDS

1 st gear	2.23 Km/hr
2 nd	3.54 Km/hr
3 rd	4.68 Km/hr
4 th	5.80 Km/hr
5 th	9.70 Km/hr
Reverse gear	3.90 Km/hr

<u>CLUTCH</u>	Dry, double clutch plates for transfer travel, 2nd for PTO shaft. Actuation through a diaphragm plate spring ensuring longer clutch life at constant operating pressure.
<u>STEERING BRAKES</u>	Recalculating ball type.
Foot operated	Hydraulic, shoe type, two pedals with latch to brake the wheels simultaneously and independently
Emergency/parking	Band type mechanical control.
<u>PTO SHAFT</u>	
Standard revolution at engine RPM 2000	540 RPM. Clockwise, viewed facing driving end.

TRANSFER GEAR BOX

1 st gear	273.2 RPM
2 nd	454.0 RPM
3 rd	639.5 RPM
4 th	797.2 RPM
5 th	1331.6 RPM
Reverse gear	534.0 RPM

HYDRAULIC POWER LIFT SYSTEM

Working pressure max	150±10 kg/cm ²
Output of hydraulic power lift pump	20 litres at 540 RPM of PTO Shaft
Lifting capacity on ends of tie rods/800 length	1700 Kg

ELETRICAL EQUIPMENT

Storage battery	2x12V
Dynamo	12V/12 Amp
Voltage regulating relay	12V/12 Amp
Starter	12V/4 HP

TYRES

Front	6.5-20
Rear	16.9/14-28

MAIN DIMENSION AND WEIGHTS

Overall length	3655 mm	
Overall width at rear wheel track 1420 mm	1850 mm	
Height upto upper rim of steering wheel	1761 mm	
Max. height with upper exhaust	2220 mm	
Height of swinging drawbar from ground	460 mm	
Ground clearance	470 mm	
Wheel base	2250 mm	
Front wheel track adjustable	1295-1390-1765 mm	
Rear wheel track adjustable	1420,1480,1590,1650,1700,1760 mm	
Min. turning radius with braking one wheel	3.4+0.25 m	
Ballast weights		
Rear wheels (6 pcs)	175 kgs (Standard)	Total 315 kgs
Rear wheels (4 pcs)	140 kgs (Optional)	
Front axle (6 pcs below the pan)	160 kgs (Optional)	Total 390 kgs
Front axle (10 pcs in front of the pan)	230 kgs (Optional)	
Weight of water in rear tyres	2x150 kgs	
Weight of tractor in standard design	2550 kgs	
There from – Front axle load	910 kgs	
- Rear axle load	1640 kgs	
Weight of tractor when fully ballasted	3325 kgs	
Water in tyres only 230 kgs.Front axle ballast wts. Not included		
There from – Front axle load	1020 kgs	
- Rear axle load	2305 kgs	
Tractive force at suspension with additional ballast weight	2600 kgs	