

DIRECTOR GENERAL BORDER ROADS
GENERAL MAINT INSTRUCTION NO. 145

ON

CARBURETOR FUEL STARVATION : CAR 5 CWT WILLYS QJBB

Introduction

1. Units holding the subject vehicle fitted with fuel filter between pump and carburetor may take the following action given in para 4, if fuel starvation is observed.

Item effected

2. Fuel filter.

Action by

3. All user units/Field wksp (GREF).

Details

4. a) Inspect the fuel filter bowl from time to time and if impurities such as dust or water have collected in it, the bowl shall be removed and cleaned after loosening the clamp nut. Inspect joints for any leakage.
- b) The first cleaning will be done after 5000 Kms. Remove the filter assy, dismantle and clean the fuel filter element and bowl with gasoline to remove dirt and water. Blow compressed air through the outlet and again clean with gasoline. Make entries in the Log-Book.
- c) Repeat the task mentioned at (b) above at every 2000 Kms thereafter.
