

LUBRICATION AND SERVICING SCHEDULE: ROAD ROLLER

Nomenclature	Daily	Every 50 Hrs	Every 100 Hrs	Every 200 Hrs	Every 500 Hrs	Every 1000 Hrs
Engine	Check Oil level and top up 2. Tighten all nuts, Bolts and other electric connections. 3. Check for any leakage.	-	Change oil and check with dip stick	Change oil	1. Remove sump and clean 2. Clean oil strainer in sump	-
Oil Pump	Check oil pressure while running	-	-	-	-	-
Air Cleaner	Check oil level	1. Check oil level and fill up to level 2. Clean element	Clean element and change the oil	Clean element and change oil	-	-
Battery, Dynamo and starter	See that battery terminals leads are clean	Top up battery with distilled water	Refill grease on Dynamo	Refill Grease on dynamo	-	-
Oil Filter	-	Drain sledge	Clean element	Change element	-	-
Fuel Filters	-	Drain Sledge	Clean pre-filter element	Clean pre-filter element	-	Change paper filter element
Fuel Tank	Check fuel in tank	-	-	-	-	Remove and clean
Cooling system	Check water level and top up	Check fan belt and adjust	-	-	Flash out Radiator	Flash out radiator
Transmission	-	Check oil level and top up	-	-	Change oil	-
Front Roller yoke & Pins	Lubricate with grease	-	-	-	-	-

Hard steering gear	Lubricate with oil	-	-	-	-	-
Steering shaft universal coupling	Lubricate with grease	-	-	-	-	-
Clutch operating fork	Lubricate with grease	-	-	-	-	-
Brake linkage	-do-	-	-	-	-	-
Rear Roller axle	Lubricate with grease	-	-	-	-	-
Driving ring gear	Lubricate with oil	-	-	-	-	-
Clutch slide	Lubricate with oil	-	-	-	-	-